

1.

Carefully scrape away any unevenness or flash with a scalpel, but make sure you do not scrape away the marks for the pillow bearings.



2.

Glue the four pillow bearings onto the chassis rails, inbetween the marks.



3.

Put a SMALL drop of glue into the bottom of the axle holder. Put a wheel set into the holder, and put another SMALL drop of glue on top. You may find on your kit that some of the holder side wall has not come out in the moulding process. This is NOT a problem, there will still be plenty of side wall left for the axle tube to fit tightly and correctly.



4.

Drill a 1.7mm hole into the marked dots on the buffers. Bend up two hooks from the brass wire and glue into place.



5.

Run a little glue on the end of the wagon and clip the buffer beam into place. Make sure the marked 'X's are on the same end.



6.

**That's it, finished. Now just paint.**

