

**Paint your wagon and wheel set.**



**If using an Accucraft wheel set, cut off extra axle and file stub smooth.**



**The tube has already been cut to length, so simply file the ends of the tubes smooth. Remove burs from the inside ends of the tubes. Make the edges smooth with fine wet and dry paper and with a cloth, clean out any waste from within the tubes.**



**Pull one wheel off its axle and put a small blob of oil onto the axle. Slide the tube over the axle and press the wheel back on, making sure the back to back is correct for your gauge.**



**Put a small blob of glue onto the axle tube and place the axle set into the axle holder. Add another small blob of glue on top of the axle tube.**



**Place a number of small blobs of glue onto the base of the wagon and drop the axle sets into place, making sure the wheel sets are straight.**



**Make two hooks from the brass wire. Drill a 1.6mm hole where marked on the buffer top. Push the hooks into place, maybe with a spot of glue?**

